

MODEL	BASE FRAME AND/OR SEAT TRACK REQUIREMENT		ARM DRIVER		ARM PASS		TILT F'WD
	DRIVER	PASSENGER	IN	OUT	IN	OUT	
TOYOTA							
Toyota Forerunner 4WD 11/1983 - 09/1988	Base frame Paratus seat tracks.	Base frame Paratus seat tracks.	Y*	No	Y*	No	Y
	*Arm down cannot open console lid. Arm up -only open lid 70%.						
Toyota Forerunner 4WD 10/1988 - 11/1997	Base frame Paratus seat tracks.	Base frame Paratus seat tracks.	Y*	No	Y*	No	Y
	*Arm down cannot open console lid. Arm up -only open lid 70%.						
Toyota Hi-Lux 4WD 08/1983 - 09/1988	Base frame Paratus seat tracks.	Base frame Paratus seat tracks.	Y*	No	Y*	No	Y
	*Arm down cannot open console lid. Arm up -only open lid 70%.						
Toyota Hi-Lux 4WD 10/1988 - 11/1997	Base frame Paratus seat tracks.	Base frame Paratus seat tracks.	Y*	No	Y*	No	Y
	*Arm down cannot open console lid. Arm up -only open lid 70%.						
	PASSENGER 60% ONLY:		No	No	No	No	Y
	NB: O.E. 60% Passenger Seat replacement:-						
	Must be installed by a Paratus approved seat installer.						
	Bucket Seat, seat belt stalk and bolt to be procured from Toyota spare parts.						
	Date of Manufacture as shown on compliance plate to be supplied to Toyota to ensure correct part is obtained.						
	Note: If Driver's bucket seat & 60 % seat are replaced, the adjustment bar on the Driver's seat will protrude 48 mm further forward as compared to the passenger seat.						
Toyota Hi-Lux 2WD or 4WD 10/1997 To 04/2005	Base frame with seat belt anchorage Paratus seat tracks.	Base frame with seat belt anchorage Paratus seat tracks.	No	No	No	No	No
All models except "Workmate" (ie seat and ½ can be replaced but cannot replace bench seat in "Workmate")	Bucket Driver & Passenger seat and a half:						
	If both D&P replacd Armrests can be fitted. If Driver seat only is replaced Armrest cannot be fitted as it will foul on the seat and a half						

MODEL	BASE FRAME AND/OR SEAT TRACK REQUIREMENT		ARM DRIVER		ARM PASS		TILT F'WD
	DRIVER	PASSENGER	IN	OUT	IN	OUT	
Toyota Hi-Lux 2WD or 4WD 04/2005 Onwards	Base frame with seat belt anchorage Paratus seat tracks.	Base frame with seat belt anchorage Paratus seat tracks.	No	No	No	No	Y
Toyota Hi-Lux 60% Passenger Bench Seat 04/2005 Onwards All models except		Base frame with seat belt anchorage Paratus seat tracks.	-	-	Y	No	Y
'Workmate' Full bench seat Cannot Replacefull bench seat.							
Toyota LandCruiser 60 Series 1981 - 08/1987 • 2 round headlights * OK if no console.	No base frame Existing seat tracks.	No base frame Existing seat tracks. If existing seat is a Bucket seat.	Y*	No	Y*	No	Y
**REFER NOTE BELOW							
PASSENGER ONLY:							
<p>NB: If existing seat is a seat and a half a base frame and seat belt stalk are required.</p> <p>NB: Driver's seat belt stalk to be obtained & used for passenger seat. To be procured from toyota Spare Parts. VIN (Vehicle Identification Number), Date of manufacture and Trim colour-shown on compliance plate, located in engine compartment to be supplied to Toyota to ensure correct part is obtained.</p> <p>PLEASE NOTE: Driver's Inner seat track may be required for Paratus passenger Bucket seat installation, (inner track position), in some 60 Series models.</p> <p>We recommend a trial fitment of the existing track in the Bucket seat position to ensure compatibility.</p>							
Toyota LandCruiser 61 & 62 Series 08/1987 - 1990 Excluding the Sahara with height adjuster. Cannot separate tracks from height adjuster. • 4 square headlights * OK if no console	No base frame. Existing seat tracks.	No Base frame Existing seat tracks. If existing seat is a Bucket seat.	Y*	No	Y*	No	Y
**REFER NOTE BELOW							
PASSENGER ONLY:							
<p>NB: If existing seat is a seat and a half the following items are required. Base frame Existing outer set track.</p> <p>O.E. inner seat track. O.E. seat mounting bracket.</p> <p>Refer Price List for cost.</p> <p>O.E. Driver's seat belt stalk used in passenger position. Seat belt to be procured from Toyota Spare Parts. VIN (Vehicle Identification Number), Date</p>							

MODEL	BASE FRAME AND/OR SEAT TRACK REQUIREMENT		ARM DRIVER		ARM PASS		TILT F'WD
	DRIVER	PASSENGER	IN	OUT	IN	OUT	
Toyota LandCruiser Troop Carrier / Cab Tray 75 Series Driver & Passenger	of manufacture and Trim colour-shown on compliance plate, located in engine compartment to be supplied to Toyota to ensure correct part is obtained						
	Base frame	Base frame	Y*	No	Y	No	Y
	Existing seat tracks.	Existing seat tracks.					
		Passenger seat locating template is required for fitting PABB-					
	* Just touches inner 60% in up position if O.E. Pass. Seat is retained.						
	PASSENGER ONLY:						
Same as - FJ73 and FJ75	Must be installed by a Paratus approved seat installer.						
	<p align="center">NB: Driver's seat belt stalk to be obtained & used for passenger seat. To be procured from Toyota Spare Parts.</p> <p align="center">VIN (Vehicle Identification Number), Date of Manufacture and Trim colour-shown on compliance plate, located in engine compartment to be supplied to Toyota to ensure correct part is obtained</p>						
	IF O.E. PASSENGER SEAT IS TILT SWIVEL						
	<ul style="list-style-type: none"> NB: Cannot retain tilt and swivel base on passenger side O.E. seat tracks required for fitting. To be procured from Toyota Spare Parts. Date of manufacture is required 						
	Forwards & Rearwards Sliding tracks are required.						
70, 78 & 79 Series Driver & Passenger	DRIVER BUCKET		PASSENGER BUCKET				
	Base frame	Base frame	Y*	No	Y	No	Y
	Existing seat tracks.	Existing seat tracks.					
	* Just touches inner 60% in up position if O.E. Pass. Seat is retained.						
	PASSENGER ONLY - SEAT & 1/2 REPLACEMENT						
		Seat Belt Stalk					
		Plate Adaptor-Refer Price List					
	NB: Driver's seat belt stalk to be obtained & used for passenger seat. To be procured from Toyota Spare Parts.						
	VIN (Vehicle Identification Number), Date of Manufacture and Trim colour-shown on compliance plate, located in engine compartment to be supplied to Toyota to ensure correct part is obtained						
	IF O.E. PASSENGER SEAT IS TILT SWIVEL						
	<ul style="list-style-type: none"> NB: Cannot retain tilt and swivel base on passenger side O.E. seat tracks required for fitting. To be procured from Toyota Spare Parts. Date of manufacture is required 						
	Forwards & Rearwards Sliding tracks are required.						
	IF O.E. PASSENGER BUCKET SEAT IS TILT & SLIDE FORWARD						
	<ul style="list-style-type: none"> NB: Cannot replace with Paradrive (Paratus) seat 						
Toyota LandCruiser 76Series Wagon - Bucket seats only	Base frame	Base frame	Y	No	Y	No	Y
	Existing seat tracks.	Existing seat tracks.					
	* If centre console Fitted.						
	*Arm down cannot open console lid. Arm up -only open lid 70%.						

MODEL	BASE FRAME AND/OR SEAT TRACK REQUIREMENT		ARM DRIVER		ARM PASS		TILT F'WD
	DRIVER	PASSENGER	IN	OUT	IN	OUT	
Toyota LandCruiser 80 Series RV, GXL, GXL Turbo	Base frame	Base frame	Y	No	Y*	No	Y
	Existing seat tracks.	Existing seat tracks.					
DRIVER & PASSENGER:							
<p>Must be installed by a Paratus approved seat installer. Rework to O.E. inner seat track requires removal of O.E. seat belt bracket. The seat belt bracket cannot be re-used to reinstate the original seat.</p>							
* Must lift arm to gain access to console on Passenger side only.							
Toyota LandCruiser 80 Series Standard & DX	Base frame	Base frame	Y	No	Y*	No	Y
	Existing seat tracks.	Existing seat tracks.					
DRIVER ONLY							
<p>Must be installed by a Paratus approved seat installer. Rework to O.E. inner seat track on bucket seats requires removal of O.E. seat belt bracket. The seat belt bracket cannot be re-used to reinstate the original seat.</p>							
PASSENGER ONLY							
<p>Must be installed by a Paratus approved seat installer. O.E. 60% Passenger seat replacement:- GXL Bucket Seat seat belt stalk and bolt and GXL Passenger seat inner track, required to be procured from Toyota Spare Parts. Date of Manufacture as shown on compliance plate to be supplied to Toyota to ensure correct part is obtained.</p>							
Toyota LandCruiser 100 Series RV, GXL,GXV	Base frame with seat belt anchorage.	Base frame with seat belt anchorage.	No	No	No	No	No
	Paratus seat tracks.	Paratus seat tracks.					
Toyota LandCruiser 100 Series Standard	Base frame with seat belt anchorage.	Base frame with seat belt anchorage.	Y	No	Y	No	No
	Paratus seat tracks.	Paratus seat tracks.					
PASSENGER ONLY:							
<p>GXL Passenger seat belt stalk and bolt required. To be procured from Toyota Spare parts. Date of Manufacture as shown on compliance plate to be supplied to Toyota to ensure correct part is obtained. <u>ALL TOYOTA 100 SERIES VEHICLES RV, GXL, GXLV & STD</u></p>							
<p>NOTE: CANNOT INSTALL A PARATUS SEAT INTO THE DRIVER OR PASSENGER SEAT LOCATIONS IF THE TOYOTA SEAT HAS A SENSOR WHICH DETECTS AN OCCUPANT FOR DEPLOYMENT OR NON DEPLOYMENT OF THE AIR BAG.</p>							
MUST CHECK TOYOTA VEHICLE MANUAL.							

MODEL	BASE FRAME AND/OR SEAT TRACK REQUIREMENT		ARM DRIVER		ARM PASS		TILT F'WD
	DRIVER	PASSENGER	IN	OUT	IN	OUT	
Toyota Camry 1987 - 1994	Unable to fit.	Unable to fit.	-	-	-	-	-
Toyota Hi Ace Van 1994 onwards	Unable to fit.	Unable to fit.	-	-	-	-	-
Toyota Prado	Unable to fit.	Unable to fit.	-	-	-	-	-

NB:

- **Installations **NOT** requiring a Base Frame cannot be transferred to a different vehicle without a Factory rework. (Inclusive of 60, 61 & 62 Series Passenger Seats). Similarly, installations **requiring** a Base Frame cannot be transferred to a vehicle **not requiring** a Base Frame without a Factory rework.
- Both Front seats must tilt in a two-door vehicle if the vehicle has Rear seats.